

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-94

Киргизия (996)312-96-26-47 Казахстан (772)734-952-31 Таджикистан (992)427-82-92-69

<http://www.rotair.nt-rt.ru> || rri@nt-rt.ru

ПОРТАТИВНЫЕ КОМПРЕССОРЫ

ТЕХНИЧЕСКОЕ ОПИСАНИЕ



DESCRIPTION	FREE AIR DELIVERY(ISO 1217)		OPERATING PRESSURE		ENGINE	DRIVE	EMISSIONS COMPLIANCE
	lt/min	CFM	bar	psi			
MDVN 22 K	2000	71	6.5	94	Kubota	Belt drive	EU – US
MDVN 26 K	2500	90	6.5	94	Kubota	Belt drive	EU – US
MDVN 31 K	3000	106	7	102	Kubota	Direct drive	EU – US
MDVN 31 P	3000	106	7	102	Perkins	Direct drive	–
MDVN 37 K	3600	127	7	102	Kubota	Direct drive	EU – US
MDVN 37 P	3600	127	7	102	Perkins	Direct drive	–
MDVN 46 K	4500	159	7	102	Kubota	Direct drive	EU – US
MDVN 46 P	4500	159	7	102	Perkins	Direct drive	–
MDVN 53 K	5200	185	7	102	Kubota	Direct drive	EU – US

MDVN 53 P	5200	185	7	102	Perkins	Direct drive	–
MDVN 53 PTA (higher than 3000 mt a.s.l.)	5200	185	7	102	Perkins	Direct drive	–
MDVN 72 K	7100	251	7	102	Kubota	Direct drive	EU – US
MDVN 72 D	7100	251	7	102	Deutz	Direct drive	–
MDVN 81 K	8200	290	7	102	Kubota	Direct drive	EU – US
MDVN 81 D	8000	283	8	116	Deutz	Direct drive	–
MDVN 86 D	8500	300	7	102	Deutz	Direct drive	–

DESCRIPTION	EMISSIONS COMPLIANCE	FREE AIR DELIVERY		OPERATING PRESSURE	
		lt/min	cfm	bar	psi
MDVS 95 P	–	9500	335	12	174
MDVS 95 P	EU – US	9500	335	12	174
MDVS 105 P	–	10500	371	10	145
MDVS 105 P	EU – US	10500	371	10	145
MDVS 120 P	–	12000	424	7	102
MDVS 120 P	EU – US	12000	424	7	102
MDVS 95 J	–	9500	335	12	174
MDVS 95 J	EU – US	9500	335	12	174
MDVS 105 J	–	11000	388	10	145
MDVS 105 J	EU – US	11000	388	10	145
MDVS 120 J	–	12000	424	7	102
MDVS 120 J	EU – US	12000	424	7	102
MDVS 170 J	EU – US	17000	600	7	102
	EU – US	16800	593	8,6	125
	EU – US	15000	530	10	145
	EU – US	13000	459	12	174
	EU – US	12000	424	14	203
	EU – US	11700	413	15	218
MDVS 150 P12	US	15000	530	12	174
MDVS 165 P10	US	16500	583	10	145
MDVS 185 P8	US	18500	653	8	116
MDVS 200 P12	US	20500	724	12	174
MDVS 230 P10	US	22700	802	10	145
MDVS 255 P8	US	25300	893	8	116

DESCRIPTION	EMISSIONS COMPLIANCE	FREE AIR DELIVERY		OPERATING PRESSURE	
		lt/min	cfm	lt/min	cfm
GOMMAIR 10 – 7	EU – US	1100	39	7	102
GOMMAIR 10 – 11	EU – US	930	33	11	160
GOMMAIR 10 -13	EU – US	800	28	13	189
VRK 120 AE	EU	1200	42	6	87
	EU	850	30	11	160
	EU	750	26	13	189
VRK 130 AE	EU	1350	48	6	87
VRK 160 AE	EU – US	1600	57	6	87

DESCRIPTION	EMISSIONS COMPLIANCE	FREE AIR DELIVERY		OPERATING PRESSURE	
	EU – US	1200	42	8	116
	EU – US	1050	37	11	160
	EU – US	950	34	13	189
VRK 190 AE	–	1800	64	6	87
VRK 180 AE	–	1800	64	6	87
VRK 200 AE	EU – US	1900	67	6	87
	EU – US	1600	57	8	116
	EU – US	1220	43	11	160
	EU – US	950	34	13	189
VRK 220 AE	–	2150	76	6	87
VRK 185 D DIESEL	EU – US	1800	64	7	102

Description	MIN WORKING PRESSURE		FREE AIR DELIVERY		OPERATING PRESSURE	
	bar	psi	lt/min	cfm	bar	psi
VRH 10/8	5.5	79	1000	35	7	102
VRH 10/10	5.5	79	1000	35	10	143
VRH 10/13	5.5	79	1000	35	13	188
VRH 15/8	5.5	79	1500	53	7	102
VRH 15/10	5.5	79	1500	53	10	143
VRH 15/13	5.5	79	1500	53	13	188
VRH 20/8	5.5	79	2000	71	7	102
VRH 20/10	5.5	79	2000	71	10	143
VRH 20/13	5.5	79	2000	71	13	188
VRH 25/8	5.5	79	2500	88	7	102
VRH 25/10	5.5	79	2500	88	10	143
VRH 25/13	5.5	79	2500	88	13	188
VRH 30/8	5.5	79	3000	106	7	102
VRH 30/10	5.5	79	3000	106	10	143
VRH 30/13	5.5	79	3000	106	13	188
VRH 35/8	5.5	79	3500	124	7	102
VRH 35/10	5.5	79	3500	124	10	143
VRH 35/13	5.5	79	3500	124	13	188
VRH 40/8	5.5	79	4000	141	7	102
VRH 40/10	5.5	79	4000	141	10	143
VRH 40/13	5.5	79	4000	141	13	188
VRH 50/8	5.5	79	5000	177	7	102
VRH 50/10	5.5	79	5000	177	10	143
VRH 50/13	5.5	79	5000	177	13	188
VRH 55/8	5.5	79			7	102
VRH 55/10	5.5	79			10	143
VRH 55/13	5.5	79			13	188
VRH 60/8	5.5	79	6000	212	7	102
VRH 60/10	5.5	79	6000	212	10	143
VRH 60/13	5.5	79	6000	212	13	188
VRH 70/8	5.5	79	7000	247	7	102
VRH 70/10	5.5	79	7000	247	10	143
VRH 70/13	5.5	79	7000	247	13	188

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-92

Киргизия (996)312-96-26-47 Казахстан (772)734-952-31 Таджикистан (992)427-82-92-69

<http://www.rotair.nt-rt.ru> || rri@nt-rt.ru